
100R5 Hydraulic Fittings




! CAUTION

- 1. Disassemble the fittings in reverse order.
- 2. Do not attempt to assemble these fittings to the hose without using a mandrel.


Assembly



1. Screw hose into socket (left hand thread) until it bottoms. Back out hose 1/4 turn.



2. Slide the insert onto the mandrel. Lubricate the hose ID and the insert of the sub-assembly with lubricating oil or light grease.



3. The insert is then threaded into the socket and hose. Leave $^{1}/_{16}$ inch clearance so nut is free to swivel.

Maintenance

- 1. Clean the hose assembly by blowing out with air.
- 2. Inspect the hose by looking through the assembly for any possible obstructions or foreign matter. Clean hose ID as necessary.
- 3. Swivel nuts should turn freely.
- 4. Check the layline of the hose to be sure the assembly is not twisted.
- 5. Cap the ends of the assembly to keep clean.

Parts List

Part Description	Part Number
assembly tool for HS1488 end fitting size (-04) assembly	B22811
assembly tool for HS1488 end fitting size (-05) assembly	B22812
assembly tool for HS1488 end fitting size (-06) assembly	B22813
assembly tool for HS1488 end fitting size (-08) assembly	B22814
assembly tool for HS1488 end fitting size (-10) assembly	B22815
assembly tool for HS1488 end fitting size (-12) assembly	B22816
assembly tool for HS1488 end fitting size (-16) assembly	B22817
assembly tool for HS1488 end fitting size (-20) assembly	B22818